

ELD500 PRECISION LEAK DETECTOR

 **EDWARDS**





EDWARDS THE PARTNER OF CHOICE

Edwards is a world leader in the design, technology and manufacture of vacuum pumps with over 95 years of history and more than 75 years of manufacturing experience.

We believe in delivering results that bring value to our customers by using our breadth of industry experience to identify and apply solutions to your problems. Using the most innovative and up-to-date modeling techniques, we can optimise the pumping configuration for customers to provide a system design giving the maximum performance in the most reliable and cost-effective way.

ELD500 PRECISION LEAK DETECTOR

Efficient and reliable performance

Edwards new ELD500 fully automated leak detector has arrived. It's designed for fast, accurate leak detection in a wide range of applications and is fully mobile with an easy to use control interface. Edwards ELD500 is your perfect partner in leak detection.

- Low cost of ownership
- Ready to go mobile solution
- Customisable for any application
- High stability and accuracy

Applications

Analytical Instruments

- Electron microscopy
- Leak detection
- Mass spectrometry
- Surface analysis

Research and development

- Space simulation
- Cryogenic research
- Nanotechnology
- Coating systems

Semiconductor

- Load lock
- Transfer
- Metrology
- Lithography
- PVD (physical vapour deposition)
- Plasma etching
- Implant source
- CVD (chemical vapour deposition)
- Flat panel display
- LED

Industrial

- Industrial leak detection
- Electron beam welding
- Lamp and tube manufacturing
- Glass coating
- Brake line and air conditioning
- Refrigeration system manufacturers
- Heat treatment
- Power
- Vacuum furnaces

High energy physics

- Beam lines
- Accelerators
- Fusion
- Laser evacuation



Low cost of ownership

The proven design of the Edwards ELD500 leak detector, combined with low energy consumption, extended warranty and even longer life ion source, ensures exceptional low cost of ownership with no compromise on performance.

- High efficiency and low operating power consumption
- Highly reliable product with long maintenance intervals and low part replacement requirements
- Long life ion source with a 30 month warranty



Ready to go mobile solution

Edwards ELD500 is truly ready to go in under two minutes from power on. Users can benefit from simple pass/fail readings through to detailed analysis via the easy to read control interface, and due to the low weight and integrated carry handles, it is mobile enough to be bench top or trolley mounted.

- Large clear graphical display with direct access to key functions for incredible ease of use
- Truly portable with weight from only 30 kg and accessories including a trolley with space for an additional pump and a helium gas bottle
- The leak detector can be transported in any orientation and can be ordered with an optional transport case on wheels for true portability
- Rapid start up, from power on to first measurements in only 107 seconds



Customisable for any application

With three variants in the range, FLEX, WET and DRY, plus an extensive catalogue of accessories, the versatile Edwards ELD500 leak detector is ideal across all applications. At the push of a button the ELD500 can easily be set to work in either vacuum mode for precise measurement of leak rate or sniffer mode for identifying leak location.

- All models feature a rugged turbomolecular pump optimised for the rigours of portable leak detection
Variants include

- WET version with an integrated oil sealed rotary vane pump
- DRY version with an integrated helium optimised diaphragm pump
- FLEX version without a primary pump, ideal for trolley mounting along with a larger primary pump such as an Edwards nXDS scroll pump

- Flexible remote control options, features include

- Colour touch screen control with local graphical display
- Audible leak indication via loudspeaker or headphones
- Data logging to local memory or USB stick
- Wired or wireless models available
- Wireless model allows simultaneous control of up to 10 leak detectors

- The partial flow kit allows effective pump down of large or contaminated volumes

- Compatible with WET and FLEX variants
- Allows automatic calculation and display of actual leak rate
- Enables leak detection from atmospheric pressure

- Extensive range of sniffer lines available for accurate pin-pointing of leaks on pressurised systems

- Standard sniffer line enables operation up to 4m from the ELD500
- Longer sniffer lines of up to 50m can be used with the sniffer extender interface



High stability and accuracy

Excellent repeatable accuracy is achieved by the Edwards ELD500 through calibration with the integrated test leak source and high quality mass spectrometer. Whether being used on a production line, where consistent measurement repeatability is critical, or in a laboratory environment, typically requiring the measurement of extremely low leak rates, the ELD500 is your perfect partner.

- Automated, simple, high accuracy calibration possible via the integrated long life calibrated test leak
- Optional external calibrated test leaks available for applications requiring precision accuracy traceable to international and customer/company standards
- Excellent long term stability ensured by class leading 180 degree mass spectrometer
- Fastest recovery following helium contamination thanks to highest helium pumping speed in fine mode
- High sensitivity leak detection with measurement of leak rates for Helium of $<5 \times 10^{-12} \text{mbar ls}^{-1}$ in vacuum mode and $<7 \times 10^{-9} \text{mbar ls}^{-1}$ in sniffer mode



Technical data

ELD500 Leak Detector	Units	WET	DRY	FLEX
Lowest detectable helium leak rate				
Vacuum operation	mbar ls ⁻¹	$\leq 5 \times 10^{-12}$	$\leq 3 \times 10^{-11}$	$\leq 5 \times 10^{-12}$ *
Sniffer operation	mbar ls ⁻¹	$\leq 7 \times 10^{-9}$	$\leq 7 \times 10^{-9}$	$\leq 7 \times 10^{-9}$
Maximum measurable helium leak rate				
Vacuum operation	mbar ls ⁻¹	> 0.1	> 0.1	> 0.1
Measurement ranges	decades	12	12	12
Maximum permissible inlet pressure	mbar	15	15	15
Pumping speed during pumpdown, 50 Hz/60 Hz	m ³ h ⁻¹	2.5/3	1.6/1.8	N/A
Helium pumping speed in the fine mode	ls ⁻¹	3.1	3.1	3.1
Time constant for leak rate signal	s	< 1	< 1	< 1
Time until ready for operation	min	≤ 2	≤ 2	≤ 2
Power consumption	VA	420	350	200
Inlet flange		NW25	NW25	NW25
Dimensions (WxHxD)	mm	495x456x314	495x456x314	495x456x314
Weight	kg	40	35.5	30

* backing pump dependent

Ordering information

Product Description	Order Number
ELD500 WET, 200-240V,50/60Hz	D13510903
ELD500 WET, 100-120V, 50/60Hz	D13510904
ELD500 WET, 100-120V, 60Hz	D13510906
ELD500 DRY, 200-240V,50/60Hz	D13520903
ELD500 DRY, 100-120V, 50/60Hz	D13520904
ELD500 DRY, 100-120V, 60Hz	D13520906
ELD500 FLEX, 100-240V,50/60Hz	D13530000
ELD500 RC - Wired - Remote control	D13550100
ELD500 RC - Wireless - Remote control	D13550110
ELD500 RC - Wired - 8m extension cable	14022
ELD500 RC - Wireless - Extra transmitter	D13550130
ELD500 SL - Standard sniffer line 4m	D13550300
ELD500 SL - Extended SL Interface	D13550200
ELD500 SL - Extended sniffer line 5m	14008
ELD500 SL - Extended sniffer line 20m	14009
ELD500 SL - Extended sniffer line 50m	12183
ELD500 Partial flow adaptor	D13550400
ELD500 Transport Case	D13550500
ELD500 Cart without Ebox	D13550600
ELD500 SG - Helium spray gun	16555
CL-Internal calibrated leak	D13550910
CL-Cal Leak bspk. 0.5 - 1E-7. Screw Skt	D13550930
CL-calibrated leak HE 4 to 6	D13550950

Extended warranty

Product Description	Order Number
Extended warranty from 18 months to 3 yrs	EW3AA5100
Extended warranty from 18 months to 5 yrs	EW5AA5100





Global contacts

Publication Number: 3601 0418 01
 © Edwards Limited 2018. All rights reserved
 Edwards and the Edwards logo are trademarks of
 Edwards Limited

Whilst we make every effort to ensure that we
 accurately describe our products and services,
 we give no guarantee as to the accuracy or
 completeness of any information provided in
 this brochure.

Edwards Ltd, registered in England and Wales
 No. 6124750, registered office: Innovation Drive,
 Burgess Hill, West Sussex, RH15 9TW, UK.

EMEA

UK	+44 1444 253 000 (local rate) 08459 212223
Belgium	+32 2 300 0730
France	+33 1 4121 1256
Germany	0800 000 1456
Italy	+ 39 02 48 4471
Israel	+ 972 8 681 0633

ASIA PACIFIC

China	+86 400 111 9618
India	+91 20 4075 2222
Japan	+81 47 458 8836
Korea	+82 31 716 7070
Singapore	+65 6546 8408
Taiwan	+886 3758 1000

AMERICAS

USA	+1 800 848 9800
Brazil	+55 11 3952 5000